

## Technical Data

Brand:	CABLEMATIC			
Item:	SR17 - SR18			
Material:	ABS+MDF			
Size:	Dia50cm, H6cm			
Color:	white / black			
Switch control:	ON/OFF button			
Voltage:	AC 110V-120V	AC 220V-240V		
Input Power:	4W	4W		
Certificate:	CE			FCC
Rotating mode:	electric+ manual			Manual
Rotating direction:	Clockwise		Anti-clockwise	
Rotating degree:	360 degree			
Rotating speed (Load capacity):	0.75rpm (30kg)	0.5rpm (50kg)	0.25rpm (50kg)	
Packaging:	1pcs/PE bag/foam/box; 3pcs/ctn			
Ctn:	600*580*370mm			
N.W.:	13.00kg/ctn			
G.W.:	15.5kg/ctn			

## User Instruction

1. Place the turntable horizontally;
2. Plug in the power socket;
3. Turn the switch ON "—", then it will rotate automatically;
4. During rotating, you can manually adjust the displayed goods, without affecting its rotation.
5. Keep the turntable away from water.
6. Keep the turntable out of reach of children under 3 years.