

Technical Data

Brand:	CABLEMATIC			
Item:	SR19			
Material:	MDF			
Size:	Φ80cm, THK13cm			
Color:	white / black			
Remote control:	ON/OFF	Direction		
Voltage:	DC12V			
Power:	14W			
Certificate:	CE	FCC	3C	
Rotating mode:	motorised			
Rotating direction:	Clockwise + Anti-clockwise			
Rotating degree:	360 degree			
Rotating speed:	optional speed: 2rpm, 1.5rpm, 1rpm			
Load capacity:	250kg			
Packaging:	1pcs/PE bag/foam/ctn			
Carton:	92X92X26CM			
N.W.:	21.0kg			
G.W.:	24.0kg			

Munual Instruction

1. Place the turntable horizontally;
2. Plug in the power socket;
3. Turn the switch ON "—", and press the power button on the remote, then it rotates;
4. During rotating, you can press "+" to accelerate or press "-" to decelerate.
5. Press twice the direction button to clockwise or anticlockwise rotation.
6. Keep the turntable away from water.
7. keep the turntable out of reach of children under 3 years.